

MAC 10[®] LE-DC 4x4

FAMILY OF FAN FILTER UNITS

USED IN:
- MICROELECTRONICS
- MEDICAL DEVICE
- SEMICONDUCTOR
- DISK DRIVE
- LABORATORY
- PHARMACEUTICAL
- MARKETS
- HOSPITALS
- CLEAN ROOMS



Clean air solutions built for you.▶▶

MORE INFORMATION AVAILABLE AT WWW.ENVIRCO-EMEA.COM

■ MAC 10[®] LE-DC 4x4 Introduction

The MAC 10[®] is designed for the most challenging cleanroom applications. It offers significant cost savings and electrical efficiencies for large cleanrooms.

The MAC 10[®] LE-DC 4x4 maximizes energy efficiencies with its exclusive backward blower wheel design. It provides 0.45m/s airflow and up to 250Pa of ESP (External Static Pressure) capability in clean un-loaded conditions, enabling cleanroom projects to operate cost effectively.

Fewer components mean lower installed costs. With the use of the MAC 10[®] LE-DC 4x4 unit, additional savings are captured in the ceiling plenum because less grid is required and fewer electrical connections are needed. Even better, this model also provides a lower sound level than most competitive 600mm x 1,210mm fan filter units.



MAC 10[®] LE-DC 4x4

■ Standard Features

- » Low sound, low watts, low profile and low operating costs.
- » Energy efficient DC motor (1/2hp / 0.37kW).
- » Universal Controller allows the following.
 - Manual control via the integral potentiometer.
 - Remote speed control via 0-10V analogue signal.
 - Network control via ModBus[®] compatible RTU network protocol.
- » High Efficiency Particulate Air (HEPA) filter, 99.99% efficient at 0.3 micron particle size (H13).
- » 250Pa of external static pressure capability at 0.45m/s with HEPA (H13) filter in clean un-loaded conditions.
- » Aluminium construction with a mill finish for durability.
- » 230V CE marked.
- » Protective inlet ring.

■ Options

- » Ultra Low Penetration Air (ULPA) filter - 99.9995% efficient at 0.12 micron particle size (U15) and U16 filters available.
- » Monitoring and Control System – A range of Console and PLC options are available for stand-alone or integrated BMS network control solutions.
- » The exterior is available powder-coated.
- » Room-Side Replacement (RSR) available with gel seal filter. The filter is replaced from the roomside.
- » RSRE provides filter and motor/blower assembly replacement from the roomside.

■ Warranty

- » Limited 1-year warranty.

■ Specifications

Construction

Welded aluminium cabinet.





Filters

Aluminium framed High Efficiency Particulate Air (HEPA) type, with a minimum efficiency of 99.99% @ 0.3 micron (H13) aerosol challenged (zero probed). H14, U15 and U16 filters can be supplied upon request.

Motor/Blower Assembly

Direct drive, continuous duty 1/2 Hp (0.37kW) EC motor with sealed-for-life bearings and inherent overload protection. The blower assembly is electronically (dynamically) balanced and is designed to provide rated airflow through a 50% increase in initial static pressure.

■ Dimensions



Side and Angled Views

Top & Side Views

■ Performance 4x4 Standard, RSR, & RSRE

NOMINAL UNIT SIZE	MAX m/h	WATTS @ 0.45m/s	UNIT WEIGHT (kg)
Standard	3,315	105	61.23
RSR & RSRE	3,230	115	68.04

NOTES:



Test data is taken with a vane anemometer at 0.45m/s in clean un-loaded conditions (0Pa ESP).

Full Load Current; 230V, 50Hz, 1 Ph = 3.2A.

The initial current exceeds 3.2A momentarily; suitable circuit breakers should be installed.

■ Performance Charts

MAC 10 LE-DC 4x4 STD HEPA (H13)



Test data taken with a vane anemometer.
 Testing performed in accordance with IEST Recommended Practices IEST-RP-CC006.3
 Includes initial clean filter pressure losses.
 Active Filter Face Area* = 1.33 m².
 % PWM = Motor Controller Pulse Width Modulation Signal

Unit Operating Amps = Watts / (Volts x Power Factor)

Power Factor

- @ 20% PWM = 0.61
- @ 40% PWM = 0.67
- @ 60% PWM = 0.71
- @ 80% PWM = 0.74
- @ 100% PWM = 0.74

Sensible Heat Gain:

Total Heat Method - Btu/hr = 3.431 x Motor Watts



Motor Efficiency Method = Btu/hr = 3.431 x .35 x Motor Watts

*Active filter face area does not include area losses due to protective screens.

**Due to variations in filter protective screens, actual values measured 152mm from filter face in accordance with IEST Standards, may vary from charted values.

■ Performance Charts

MAC 10 LE-DC 4x4 RSR HEPA (H13)



Test data taken with a vane anemometer.
 Testing performed in accordance with IEST Recommended Practices IEST-RP-CC006.3
 Includes initial clean filter pressure losses.
 Active Filter Face Area* = 1.33 m2.
 % PWM = Motor Controller Pulse Width Modulation Signal

Unit Operating Amps = Watts / (Volts x Power Factor)
 Power Factor
 @ 20% PWM = 0.61
 @ 40% PWM = 0.67
 @ 60% PWM = 0.71
 @ 80% PWM = 0.74
 @ 100% PWM = 0.74

Sensible Heat Gain:
 Total Heat Method - Btu/hr = 3.431 x Motor Watts
 Motor Efficiency Method = Btu/hr = 3.431 x .35 x Motor Watts

*Active filter face area does not include area losses due to protective screens.
 **Due to variations in filter protective screens, actual values measured 152mm from filter face in accordance with IEST Standards, may vary from charted values.





Clean air solutions built for you.

MORE INFORMATION AVAILABLE AT WWW.ENVIRCO-EMEA.COM

■ Industrial

Cleanroom Products

- » MAC 10[®] Original
- » MAC 10[®] IQ™
- » Ducted Ceiling Module (DCM)
- » AC or DC Control Systems

■ Hospital & Healthcare

Hospital & Healthcare

- » IsoClean[®] and IsoClean with Ultraviolet Light
- » IsoClean[®] CM
- » AirCeil[®]

Envirco[®] MAC 10[®] and VE5 are registered trademarks of Envirco[®], USA. Specifications subject to modifications or changes without notice. US patents 4,560,395 and 5,470,363. Other patents issued and pending in foreign countries. Special thanks to Connect2Cleanrooms for cleanroom photography.

Provided by Your Local Envirco[®] Representative:

Envirco[®] Europe, Middle East and Africa

The Cavendish Centre, Winnall Close | Winchester, Hampshire; S023 OLB, UK
tel: +44(0)1962.840465 | fax: +44(0)1962.828619
www.envirco-emea.com | email: TrionEMEAService@airsysco.com

 **ENVIRCO[®]**
Innovators in clean air technology

MAC10-LEDC4X4/1012 | Copyright ©2012 Envirco[®]. All Rights Reserved.